

Vor dem ersten Gebrauch

- Waschen Sie eventuelle grobe Produktionsrückstände auf dem Messfühler mit warmem Wasser ab, vermeiden Sie hierbei den Gebrauch von Reinigungs- bzw. Spülmitteln.
- Setzen Sie eine Batterie in das Batteriefach des Gerätes (1x AAA, nicht im Lieferumfang enthalten)

Verwendung als Thermometer

- Drücken Sie den „ON/OFF“ Knopf auf der Rückseite um das Gerät ein oder auszuschalten.
- Schieben Sie den Schalter auf der Rückseite des Gehäuses auf die Position „TEMP“.
- Verbinden Sie den Messfühler über den Klinkenstecker des Kabels mit dem Gehäuse.
- Sie können sich die zu messende Temperatur in Celsius oder Fahrenheit anzeigen lassen. Sie können die Einheit jederzeit durch Drücken der „°C/°F S/S“ Taste wechseln.
- Entfernen Sie die Schutzkappe auf dem Messfühler.

Kurzzeitmessung:

- Stechen Sie den Messfühler vorsichtig in das Grillgut und lesen Sie die momentane Temperatur im Display unter „THERMO TEMP“ des Gerätes ab.

Langzeitmessung, mit Alarmfunktion:

- Aktivieren Sie die Alarmfunktion, indem Sie den Knopf „ALARM“ auf der Rückseite des Gerätes drücken.
- Stellen Sie die gewünschte Zieltemperatur mit den Tasten „▲ MIN“ und „▼ SEC“ ein, angezeigt wird diese auf dem Display unter „SET TEMP“
- Stechen Sie den Messfühler vorsichtig in das Grillgut.
- Platzieren Sie das Thermometer auf einer vor Hitze geschützten Stelle. Nutzen Sie hierzu entweder den ausklappbaren Standfuß oder den integrierten Magneten auf der Rückseite des Gehäuses.
- Sobald Ihr Grillgut die von Ihnen zuvor festgelegte Kerntemperatur erreicht hat, wird der Alarm ausgelöst.

Verwendung als Timer

- Drücken Sie den „ON/OFF“ Knopf auf der Rückseite um das Gerät ein- oder auszuschalten.
- Schieben Sie den Schalter auf der Rückseite des Gehäuses auf die Position „TIMER“.
- Aktivieren Sie die Alarmfunktion, indem Sie den Knopf „ALARM“ auf der Rückseite des Gerätes drücken.
- Stellen Sie die gewünschte Garzeit mit den Tasten „▲ MIN“ und „▼ SEC“ ein. Sie können den Timer wieder auf 0 setzen, indem Sie beide Tasten zeitgleich drücken.
- Sobald die Zeit eingestellt wurde, starten Sie den Countdown durch Drücken der Taste „°C/°F S/S“.
- Durch erneutes Drücken dieser Taste, können Sie den Countdown pausieren.

Verwendung als Stoppuhr

- Drücken Sie den „ON/OFF“ Knopf auf der Rückseite, um das Gerät ein- oder auszuschalten.
- Schieben Sie den Schalter auf der Rückseite des Gehäuses auf die Position „TEMP“.
- Starten Sie die Stoppuhrfunktion durch Drücken der Taste „°C/°F S/S“, durch erneutes drücken wird die Messung pausiert bzw. gestoppt.
- Sie können die Stoppuhr wieder auf 0 setzen, indem Sie Tasten „▲ MIN“ und „▼ SEC“ zeitgleich drücken.

Technische Daten

Name:	Digitales Grill- und Bratthermometer
Art. Nr.:	8565
Maße	
Gehäuse:	ca. 6,3 x 1,5 x 7 cm (BxTxH)
Kabel:	ca. 80 cm lang
Messfühler:	ca. 18 cm lang
Gewicht:	ca. 0,1 kg
Batterie:	1x AAA, nicht im Lieferumfang enthalten

Service

Dieses Produkt wurde sorgfältig hergestellt und verpackt. Sollte es dennoch einmal Grund zur Beanstandung geben, wenden Sie sich bitte an Ihren Handelspartner.

Technische Änderungen und Druckfehler vorbehalten.

Entsorgung



Die Verpackung besteht aus umweltfreundlichen Materialien, die Sie über die örtlichen Recyclingstellen entsorgen können.



Werfen Sie das Grill- und Bratthermometer keinesfalls in den normalen Hausmüll! Entsorgen Sie ihn über einen zugelassenen Entsorgungsbetrieb oder über Ihre kommunale Entsorgungseinrichtung. Beachten Sie die aktuell geltenden Vorschriften. Setzen Sie sich im Zweifelsfall mit Ihrer Entsorgungseinrichtung in Verbindung.

Batterien und Akkus



Batterien bitte nicht in den Hausmüll. Jeder Verbraucher ist gesetzlich verpflichtet, Batterien bei einer Sammelstelle seiner Gemeinde / seines Stadtteils oder im Handel abzugeben. Dadurch können sie einer umwelt-schonenden Entsorgung zugeführt werden.

Auf schadstoffhaltigen Batterien finden Sie die chemischen Symbole Cd für Cadmium, Hg für Quecksilber und Pb für Blei. Batterien sind durch das oben dargestellte Zeichen gekennzeichnet.

Inverkehrbringer

TEST RITE tepro GmbH
Carl-Zeiss-Straße 8/4
D-63322 Rödermark
Mail: service@testritetepro.de
Web: www.testritetepro.de

Before first use

- Wash away any dirt left overs from the manufacturing process on the measuring sensor with warm water. Do not use any cleaners or detergents.
- Insert a battery inside the battery compartment (1 AAA battery not included with the thermometer).

Using the device as a thermometer

- To turn the device on or off press the "ON/OFF" button on the back side.
- Place the switch on the back side in the "TEMP" position.
- Connect the measuring sensor with the device using the cable connector.
- Temperature can be measured in either Celsius or Fahrenheit. You can switch between the units at any time by pressing the "°C/°F S/S" button.
- Remove the protective cover from the measuring sensor.

Short-term measuring:

- Carefully insert the measuring sensor into the grilled food. The current temperature will appear on the display under "THERMO TEMP".

Long-term measuring, the alarm function:

- Activate the alarm function by pressing the "ALARM" button on the back side of the device.
- Set the desired target temperature using the "▲ MIN" and "▼ SEC" buttons. The temperature will appear on the display under "SET TEMP".
- Carefully insert the measuring sensor into the grilled food.
- Place the thermometer in a place away from heat. Use either the folding leg or the integrated magnet on the back side of the device.
- When the grilled food is cooked and reaches the target temperature that you set, the alarm will go off.

Using the device as a timer

- To turn the device on or off press the "ON/OFF" button on the back side.
- Place the switch on the back side in the "TIMER" position.
- Activate the alarm function by pressing the "ALARM" button on the back side of the device.
- Set the desired cooking time using the "▲ MIN" and "▼ SEC" buttons. Pressing both buttons simultaneously resets the timer back to 0.
- Once you set the cooking time, you can start the countdown by pressing the "°C/°F S/S" button. The countdown can be interrupted by pressing this button again.

Using the device as a stopwatch

- To turn the device on or off press the "ON/OFF" button on the back side.
- Place the switch on the back side in the "TEMP" position.
- Activate the stopwatch function by pressing "°C/°F S/S" button. The measuring can be interrupted or stopped by pressing this button again.
- Pressing the "▲ MIN" and "▼ SEC" buttons simultaneously resets the timer back to 0.

Technical data

Name:	Digital grilling and roasting thermometer
Item number:	8565
Dimensions	
Device:	approx. 6.3 x 1.5 x 7 cm (width x depth x height)
Cable:	approx. 80 cm long
Measuring sensor:	approx. 18 cm long
Weight:	approx. 0.1 kg
Battery:	1 AAA, not included

Service

This product was carefully manufactured and packaged. If you nevertheless have a complaint, please contact your contract partner.

Subject to technical modifications and typographical errors.

Disposal



The packaging is made from environmentally friendly materials, which you can dispose of at your local recycling points.



Do not under any circumstance dispose of the digital grilling and roasting thermometer in normal household waste! Dispose of it at an approved disposal facility or at your community disposal facility. Respect the currently valid regulations. If in doubt, get in touch with your disposal facility.

Batteries and accumulators



Do not dispose of batteries in household waste. Every consumer is legally required to dispose of batteries at the local recycling point of their community/city district or at the shop. This ensures environmentally friendly disposal.

Batteries containing dangerous substances are labelled with the chemical symbols Cd for cadmium, Hg for mercury and Pb for lead. Batteries are labelled with the aforementioned symbols.

Distributor

TEST RITE tepro GmbH
Carl-Zeiss-Straße 8/4
D-63322 Rödermark
Mail: service@testritetepro.de
Web: www.testritetepro.de