


NEBO® DAVINCI® 450 FLEX



FLEX-POWER

Flex-Power allows this unit to run on the included rechargeable battery or disposable alkaline batteries.

RECHARGEABLE


Use the included charging cable to recharge the unit. Power button will indicate battery level.

POWER INDICATOR

Steady Orange: Battery more than 25%
Flashing Orange: Battery less than 25%

CHARGING INDICATOR

Pulsing Green: Battery charging
Steady Green: Battery fully charged



OPERATION


Press & release power button to turn the unit off and on and cycle through light modes:

High > Low > Off

When light is ON for 8 seconds or longer, the next button press will turn the unit off.

Strobe: Double-tap button

Turbo: From ON, press and hold power button



6X ZOOM

Twist the head to narrow or widen the light beam.

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com

If you experience a problem, please do not return to your local store. Contact our Customer Service team at **800-255-6061** or www.nebolights.com/contact

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com

BATTERY

This unit is powered by a Li-Ion battery, but can also use a standard AA battery.

PRODUCT GUARANTEE



If you experience a problem, please do not return to your local store. Contact our Customer Service team at **800-255-6061** or www.nebolights.com/contact

For more information, detailed video instructions, and warranty registration, visit NEBOLIGHTS.com