

IT Istruzioni per l'uso

Il profumo della candela si diffonde pienamente quando la cera viene riscaldata dalla fiamma e si scioglie. Quando si accende la candela per la prima volta, lasciarla accesa fino allo scioglimento dello strato superiore di cera per garantire una combustione uniforme.

Riutilizzo: dopo l'uso, il contenitore di vetro può essere usato anche come portacandele, per riporre gioielli o come elegante elemento decorativo. A questo scopo, rimuovere con cura prima i pezzi di cera più grandi, poi mettere il contenitore di vetro in acqua calda fino a quando la cera rimanente può essere rimossa. Assicurarsi che l'acqua calda non penetri nel contenitore della candela e non si mischi alla cera.

Attenzione! Non versare i residui di cera liquida nello scarico - rischio di intasamento! Se la cera aderisce ancora al vetro, pulirlo con un panno di cotone imbevuto di aceto, olio, acqua ragia o acido citrico.

Tenere fuori dalla portata dei bambini.

In caso di irritazione o eruzione della pelle: consultare un medico.



Ingredient(s):

Paraffin Wax; Palm Oil; 2-Phenylethanol; 3,7-Dimethylocta-1,6-dien-3-ol; 2-Benzylideneheptanal; 2-Benzylideneoctanal; Benzylacetate; 2-(4-Methylcyclohex-3-en-1-yl)propan-2-ol; Pentyl salicylate; 1-Methyl-1-(4-methylcyclohex-3-en-1-yl)ethyl acetate; 2H-Chromen-2-one; 3-Methyl-4-(2,6,6-trimethylcyclohex-2-en-1-yl) but-3-en-2-one; 2-Ethyl-4-(2,2,3-trimethylcyclopent-3-en-1-yl) but-2-en-1-ol; 3-Phenylprop-2-en-1-ol; 4-tert-Butylcyclohexyl acetate; (1,7,7-Trimethylbicyclo[2.2.1]hept-2-yl)- cyclohexanol; 3,7-Dimethyloct-6-en-1-ol; 4-Hydroxy-3-methoxybenzaldehyde; 1,3,4,6,7,8-hexahydro-4,6,6,7,8,8-hexamethylcyclopenta[g]-2-benzopyran; 4-Allyl-2-ethoxyphenol; 1-(3-Methoxypropoxy)propan-1-ol; 2-Isobutyl-4-methyltetrahydro-2H-pyran-4-ol; 3,7-Dimethylocta-2,6-dien-1-ol; Cedran-8-ol; 2-Methyl-3-phenylacrylaldehyde; 3-(4-Isopropylphenyl)-2-methylpropanal; 2E-3,7-Dimethylocta-2,6-dien-1-ol; 2,6-dimethyloct-7-en-2-ol; Cedr-8-ene; 1,5-Dimethyl-1-vinylhex-4-en-1-ylacetate; Methyl 3-phenylacrylate; 3-Ethoxy-4 hydroxybenzaldehyde; 1,3-Benzodioxole-5-carbaldehyde; Methyl 2,4-dihydroxy-3,6-dimethylbenzoate; Methyl 2-aminobenzoate 3-Hepten-2-one; 3,4,5,6,6-pentamethyl-, (Z)-2-Methoxy-4-prop-1-en-1-ylphenol; 2,6-Di-tert-butyl-p-cresol; 1,7,7-trimethylbicyclo[2.2.1]heptan-2-one; 3-Phenylacrylaldehyde; 2,6,6-Trimethylbicyclo[3.1.1]hept-2-ene; 6,6-Dimethyl-2-methylenbicyclo[3.1.1] heptane

GB Instructions for use

The full fragrance of the candle is released when the wax is heated by the flame and melts. When you light the candle for the first time, leave it to burn so that the top layer of wax can melt and ensure even burning.

Re-use: After use, the glass container can be reused as a tea light holder, jewellery holder or stylish decorative element. To do this, carefully remove larger pieces of wax first, then carefully place the glass container in hot water until the remaining wax can be removed. Make sure that no hot water enters the candle container and mixes with the wax.

Caution! Do not pour liquid wax residue down the drain - risk of blockage! If there is still wax on the glass, clean it with a cotton cloth soaked in vinegar, oil, white spirit or citric acid.

Keep out of reach of children.

If skin irritation or rash occurs: Get medical advice/attention.

